

								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010026	31170-5A2-A02	K24W5/RM3	DS010027	31170-5G0-A01	J30A7/CR4	DS010028	31170-5R7-A11	L15B3/B2/B5
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010029	31170-R70-A01	J35Z2/CP3	DS010030	31170-RZP-G01	CP1/GM3/FA1	DS010031	31170-P8A-A01	J30A1/J30A2
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010032	31170-PXK-J01	J30A1	DS010033	31170-R40-A02	K24Z3/CP2	DS010034	31170-RAA-A01	CM5/KA24/RD5
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010035	31170-RB0-J01	L15A7/Z1/GE6	DS010035-L	31170-RB0-J01	L15A7/Z1/GE6	DS010036	31170-RCA-A01	J30A4/J37A1
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010037	31170-RFE-006	RB1/K24A6	DS010038	31170-RNA-A01	FA1	DS010038-L	31170-RNA-A01	FA1(1/8)

								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010060	31170-P8F-A020	J30A1	DS010350	PQG100200	20T2N/20T2R	DS010419	31170-55A-003	L15Z1/L15Z4
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010420	31170-RBJ-003	LDA3/LEA1	DS010477	31170-R0A-015	R18Z2/R20A6	DS010502	31170-59B-015	L15B8/L15B9
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010503	4792112AD	EGA/EER/EGG	DS010530	31190-RL5-A00	K24Y5/K24Z5	DS010572	31170-5AY-H01	P10A1/P10A5
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010594	31170-RMX-003	LDA2	DS020017	31190-RL2-G01	GM3/RE2/CU1	DS020018	38942-PWA-004	L13A3/L15A1
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS020019	31180-PNA-003	K24A4/K20A7	DS020020	73131-FC000	EJ20/EJ25	DS020141	31190-R1A-A01	R20Z4/R18Z7

								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS020222	31190-RRA-A00	K20A/K20A2	DS030017	14510-PT0-004	CF9/CG5/RA6	DS030021	13404-PT0-004	F20B1/F20B2
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS030038	14510-RCA-A01	J30A7/J35Z2	DS030039	14550-RCA-A01	J30A7/J35Z2	DS030075	14510-P08-003	D15/D16W4
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS030085	14510-P8A-A01	J30A1	DS030093	14550-P8A-A01	J30A1	DS030097	14510-P30-003	B20Z1/B16A1
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS030106	14520PLC335		DS040016	14520-RCA-A01	J30A7/J35Z2	DS040025	14510-PNA-003	K24A4/K20A3
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS040026	14510-RNA-A01	R20A3	DS040036	14520-P8A-A01	J30A/CG2/CK1	DS050012	31141-5A2-A01	CR2/RM3/RM4

								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS050013	31141-5X6-J01	K24W5/K24V6/K24V4	DS050014	31141-RV0-A01	J35Z2	DS050036	31141-59B-J01	L15BD/L15B8
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS050118	31141-5R7-A01	L15B3/L15B2	DS050119	31141-RPY-G01	K20C3	DS050144	F-580303	N22A1/N22B2
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS050200	31141-5AY-H01	P10A1	DS060047	19200-PWA-003	L15A7/BYD473QE	DS060048	19200-RAD-A01	K24A4/K20A8
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS060049	19200-PNA-003	LDA3/K20/LEA2	DS060050	19200-RZP-003	R20A1/R18A1	DS060051	19200-RNA-A01	R18A1/GM3
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS060052	19200-RDV-J01	J30A7/J35Z2	DS060053	19200-RB0-003	L13Z1/L15A7	DS060055	19200-5A2-A01	K24Y5/K24W5

								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060161	19200-RBJ-003	LDA3	DS060242	19200-P0A-003	F20B1/F20B2	DS060295	19200-51B-H01	R18Z7/R18ZA
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060300	19200-RW0-003	LEA2	DS060322	19200-P2A-003	D14A8	DS060323	19200-P8A-A02	J30A1
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060352	19200-P01-003	B16A2/D15Z6	DS060360	19200-P75-003	B20Z1	DS060438	19200-P08-003	D15B2
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060439	19200-PY3-000	C32A	DS060440	19200-PY3-A00	C32A2	DS060441	19200-PR4-003	B16A2
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060442	19200-PH7-003	C25A1/C27A1	DS060443	19200-PLM-A01	D14Z5/D14Z6	DS060444	19200-P5A-004	C35A2

								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060465	ME996789	K20Z1/4M41	DS060539	19200-R40-003	K24Z5/K24Z2	DS060544	19200-RPY-G01	K20C3
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060576	19200-59B-003	L15B8	DS060626	19200-RBJ-003	LDA3/LEA1	DS060630	19210-PFB-003	E07Z
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS060632	GWP4155	P10A3	DS070069	DS070069	K20A8/K20A7	DS070069-1	DS070069-1	K20A8/K20A7
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS070070	DS070070	K24A1/K24A4	DS070070-1	DS070070-1	K24A1/K24A4	DS070071	DS070071	L15A7
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS070071-1	DS070071-1	L15A7	DS070072	DS070072	L15A1	DS070072-1	DS070072-1	L15A1

DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS070073	DS070073	L13A3	DS070073-1	DS070073-1	L13A3	DS070074	DS070074	R18A1
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS070074-1	DS070074-1	R18A1	DS070075	DS070075	R20A3/R20A1	DS070075-1	DS070075-1	R20A3/R20A1
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS070076	DS070076	K24Z2/K24Z3/CP2	DS070076-1	DS070076-1	K24Z2/K24Z3	DS070171	DS070171	J30A4/J35Z2
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS070241	DS070241	J30A1	DS070242	DS070242	F23Z1/F23A3	DS070322	DS070322	K24W5/CR2
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS070322-1	DS070322-1	K24W5/CR2	DS070323	DS070323	R20A8/R20A7	DS090015	DS090015	L13A3/L15A1

<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS090027	DS090027	K24V6/K24W5	DS090029	DS090029	K20A4	DS090030	DS090030	K24Z2
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS090035	DS090035	K24Z2	DS090143	DS090143	K24Z5/K24Y5	DS090178	DS090178	R20A7
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS090188	DS090188	K24A4	DS090195	DS090195	K24A6	DS100002	13810-PWA-003	L13A3/L15A1
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS120003	30520-RB0-003	L15A7	DS120007	30520-RNA-A01	R18A1/R20A1	DS120008	30520-PWC-003	L15A1
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS120015	30520-R40-007	K24Z1/K24Z3	DS120016	30520-PNA-007	A18A.K24A1	DS120025	30520-R70-S01	J35Z2

								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS120046	30521-REA-A01	R18A1/K20A3	DS120049	30520-PWA-013	L13A3	DS120058	30521-PWA-003	L13A3
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS120059	30520-R1A-A01	R18Z/R20Z/R20A	DS120060	30520-5R0-013	L15B2/L15B3	DS120061	30520-5A2-A01	K24W7/K24W
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS120069	30520-PGK-A01	D14Z6/D16V1	DS090044	DS090044	J37A1/J37A2	DS130002	53601-SNB-T02	RHD
								
<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>	<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>	<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>
DS130011	53601SDAQ03	RHD	DS130069	53601-S84-G04	LHD	DS130071	53601-SDA-A04	LHD
								
<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>	<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>	<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>
DS130077	53601-S9A-G06	LHD	DS130120	53601SWAQ01	RHD	DS130135	53400T7ST01	RHD

DS No	OEM No	Guide-Drive	DS No	OEM No	Guide-Drive	DS No	OEM No	Guide-Drive
53601-SNA-A52	53601-SNA-A52	LHD	DS130184	53601-SX8-F01	RHD	DS130285	53601-S84-A02	RHD
DS No	OEM No	Guide-Drive	DS No	OEM No	Guide-Drive	DS No	OEM No	Guide-Drive
DS130290	53601-S9A-023	RHD	DS130292	53601-TB0-P01	LHD	DS130327	53601-SWA-A01	LHD
DS No	OEM No	Guide-Drive	DS No	OEM No	Guide-Drive	DS No	OEM No	Guide-Drive
DS130597	53606-S5A-J01	RHD	53601-SCP-W01	53601-SCP-W01	LHD	51336-S04-001	51336-S04-001	RHD
DS No	OEM No	Guide-Drive	DS No	OEM No	Guide-Drive	DS No	OEM No	Application
53400-T7A-H02	53400-T7A-H02	LHD	53601TG2T01	53601TG2T01	RHD	56110-PNA-013	56110-PNA-013	RN3
DS No	OEM No	Application	DS No	OEM No	Application	DS No	OEM No	Application
56110-PT0-050	56110-PT0-050	CB3	56110-RFE-013	56110-RFE-013	RB1	56110-P2A-003	56110-P2A-003	RA1

								
DS No	OEM No	Application	DS No	OEM No	Application	DS No	OEM No	Application
56110-P8C-A01	56110-P8C-A01	CG1	56110-P0A-013	56110-P0A-013	CD5	56110-PAA-A01	56110-PAA-A01	CG5/CF9
								
DS No	OEM No	Application	DS No	OEM No	Application	DS No	OEM No	Application
56110-R40-P02	56110-R40-P02	CP2	DS130514	56110-R60-P02	CP2	56110-R70-P03	56110-R70-P03	CM6
								
DS No	OEM No	Application	DS No	OEM No	Application	DS No	OEM No	Application
DS130043	56110-RAA-A01	CM5	56110-P2A-003	56110-P2A-003	EK3	56110-RTA-003	56110-RTA-003	RE4
								
DS No	OEM No	Application	DS No	OEM No	Application	DS No	OEM No	Application
56110-RAA-A02	56110-RAA-A02	CM5	56110-PLC-013	56110-PLC-013	ES5 /ES7	DS130044	56110-RNA-A01	FA1
								
DS No	OEM No	Application	DS No	OEM No	Application	DS No	OEM No	Application
56100-PGM-053	56100-PGM-053	RA6						