

								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010011	16620-0Y040	4NR/5NR	DS010011-L	16620-0Y040	4NR/5NR	DS010062	MD367192	6G74/6G75
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS010099	23769-AA003	EZ30/30D	DS010177	23769-AA040	FB20B/FB16	DS010509	49160-64J01	M16A/M13A
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS020020	73131-FC000	EJ20/EJ25	DS020025	13073-AA142	EJ201/EJ205	DS020026	13073-AA190	EJ20/EJ25
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS020027	13073-AA230	EJ20/EJ25	DS020028	13085-AA080	EJ20/EJ25/EL15	DS020060	13505-15041	4AFE/8AFE
								
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS020121	23770-AA070	FB20B/EJ204	DS020144	23770-AA020	N32A/EZ30	DS030009	13033-AA000	EJ16/EJ202

								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS040008	13540-21010	1NZ-FE/2NZ	DS050117	23752-AA130	EJ25/FA20	DS050157	F-238163	B6ZE/Z6/L3C1
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS050160	27415-33070	MCW/DA/MCWJA	DS050249	535031610	FA20/FA20E	DS060054	21111-AA021	EJ205/EG20G
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS060152	16100-80004	1NR-FE	DS060157	21110-AA690	FB25B/FB20	DS060158	21111-AA060	EJ253/EJ25D
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS060159	21111-AA084	EJ205/EJ25	DS060294	17400-82820	G13A	DS060306	1201.H0	CFB(1KR)/1KR-FE
								
DS No	OEM No	Engine	DS No	OEM No	Engine	DS No	OEM No	Engine
DS060328	21110-AA360	EZ30	DS060345	21111-AA000	EJ20/EJ204	DS060609	21111-KA070	EN07Z

<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS070129	DS070129	FA20/FB25	DS070129-1	DS070129-1	FA20/FB25	DS070228	DS070228	EJ201/EJ253
<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>	<b>DS No</b>	<b>OEM No</b>	<b>Engine</b>
DS070304	DS070304	EJ205/EJ204	DS090245	DS090245	FB20A/FB20B	DS090267	MD367192-Z	6G74/6G75/6G72
<b>DS No</b>	<b>OEM No</b>	<b>Application</b>	<b>DS No</b>	<b>OEM No</b>	<b>Application</b>	<b>DS No</b>	<b>OEM No</b>	<b>Application</b>
34430-SC020	34430-SC020	IMPREZA	34430-FC010	34430-FC010	WRX	34430-XA011	34430-XA011	TRIBECA
<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>	<b>DS No</b>	<b>OEM No</b>	<b>Guide-Drive</b>	<b>DS No</b>	<b>OEM No</b>	<b>Application</b>
DS130322	34110-SA080	LHD	34110AE11B	34110AE11B	LHD	DS130751	34430-SC011	BPE
<b>DS No</b>	<b>OEM No</b>	<b>Application</b>	<b>DS No</b>	<b>OEM No</b>	<b>Application</b>	<b>DS No</b>	<b>OEM No</b>	<b>Application</b>
34430-FG040	34430-FG040	GRF	DS130750	34430-AG000	FORESTER	34430-SA010	34430-SA010	FORESTER